


PicoLAS

FOCUSSING POWER TO THE POINT



User Manual

Rev. 1902


LDP-V KIT

PicoLAS GmbH

Company for Innovative Power Electronics and Laser Technology

Kaiserstrasse 100
52134 Herzogenrath


Phone: +49 (0) 2407-563 58-0
Fax: +49 (0) 2407-563 58-29
E-Mail: info@picolas.de
Web: www.picolas.de



Elements of the LDP-V KIT

The LDP-V KIT includes a 15 V / 2 A wall power supply and two SMC-BNC cables to connect a compatible LDP-V or LDP-AV driver.

The SMC-BNC cables are used to connect the trigger input and current monitor output. The wall power supply provides the supply voltage for the driver.



Connectors of the KIT

Supply Voltage:

Connect the power supply for the KIT and the driver to the two pin screw terminal. Pay attention to the correct polarity!

High Voltage Input (optional):

Connect the external high voltage power supply for the driver to the two pin screw terminal. Pay attention to the correct polarity!
Disable the integrated HV supply on the driver!

Security Advice: Do not touch any leads of the HV input connector and the driver connector as they are connected to a high voltage of up to 125 V; even if no external high voltage is applied!

Mounting of the KIT

First connect the SMC-BNC cable to the trigger input and the trigger source. Connect the second SMC-BNC cable to the current monitor and an oscilloscope. Then mount the LDP-V KIT directly on top of the driver. The 10-pin female connector on the KIT must fit onto the connector of the driver. The three mounting holes on the KIT must fit on the corresponding screw terminals of the driver.

Absolute Maximum Ratings

HV-input 0 .. 125V*

Supply voltage 0 .. 15 V*

*The connected driver's limits have to be obeyed. See driver datasheet and user manual for exact specification.